


# StackPulse™ Controllers - 120 / 240 Volt AC


## Machine Mount



Specify In/Out Fittings separately

<b>M</b>	<b>M</b>	<b>A - 2</b>	<b>X</b>	<b>X</b>	<b>X</b>
W = Wall M = Machine S = Swing P = Post		# Zones 1 - 6	01 (Serial #)		
M = Mount		A = Assy	<b>VOLTAGE</b> 0 = SPECIFY 1 = 24V AC 2 = 120V AC 4 = 240V AC		


## Swing Mount



Specify In/Out Fittings separately

<b>S</b>	<b>M</b>	<b>A - 3</b>	<b>X</b>	<b>X</b>	<b>X</b>
W = Wall M = Machine S = Swing P = Post		# Zones 1 - 6	01 (Serial #)		
M = Mount		A = Assy	<b>VOLTAGE</b> 0 = SPECIFY 1 = 24V AC 2 = 120V AC 4 = 240V AC		

## Post Mount



Specify In/Out Fittings separately

<b>P</b>	<b>M</b>	<b>A - 5</b>	<b>X</b>	<b>X</b>	<b>X</b>
W = Wall M = Machine S = Swing P = Post		# Zones 1 - 6	01 (Serial #)		
M = Mount		A = Assy	<b>VOLTAGE</b> 0 = SPECIFY 1 = 24V AC 2 = 120V AC 4 = 240V AC		

CITO-FP-PRICE-22-0812